


Parts Diagram
 Models: 57130, 57131



ERC-SS-PARTS 06142022

Parts List

Models: 57130, 57131

<u>ITEM #</u>	<u>QUANTITY</u>	<u>PART #</u>	<u>DESCRIPTION.</u>	<u>RICE COOKER MODEL #</u>
1	1	57130P	RICE POT	57130, 57131
2	1	58137MC	MEASURING CUP (SMALL)	57130, 57131
3	1	58130MC	MEASURING CUP (LARGE)	57130, 57131
4	1	57130S	RICE PADDLE	57130, 57131
5	1	56932-1	RICE PADDLE (FORK STYLE)	57130, 57131
6	1	56834S	SENSOR	57130, 57131
7	1	57130LL	FRONT UPPER LATCH COVER	57130, 57131
8	1	57130UL	FRONT UPPER LATCH ASSEMBLY	57130, 57131
9	1	57130ULC	REAR UPPER HINGE COVER	57130, 57131
10	1	57130VC	VENT OUTLET CAP	57130, 57131
11	1	57130CV	S/S COVER/LID ASSEMBLY (Includes 57130VC, 57130LL, 57130UL)	57130, 57131
12	1	57130HP	HEATER PLATE (120V)	57130
	1	57131HP	HEATER PLATE (230V)	57131
13	1	57130CC	CONDENSATE COLLECTOR	57130, 57131
14	1	57176	CONTROL BOARD (120V)	57130
	1	57177	CONTROL BOARD (230V)	57131
15	1	57130FP	CONTROL HOUSING	57130, 57131
16	1	57130-L	HOUSING LABEL	57130
	1	57131-L	HOUSING LABEL	57131
17	1	57130LP	LID -HINGE PIN	57130, 57131
18	1	56829	CORD & PLUG (120V)	57130
	1	57165	CORD & PLUG (230V)	57131
19	1	57130SR	STRAIN RELIEF	57130, 57131
20	1	57179	RELAY	57130, 57131
21	1	57180	CERAMIC BLOCK	ALL MODELS
22	1	56845S	THERMOSTAT	57130, 57131
23	1	57167	WIRE SET (6 WIRES PER SET)	57130, 57131
24	1	57130BP	BOTTOM PLATE	57130, 57131
25	5	57130FT	FOOT	57130, 57131